



## **Ademco Vista Security Panel** **MyAmbience Communication Setup Guide**

***Note: Please insure that system functions independently before connecting to MyAmbience***

Ademco Vista Security Systems use a location and value based programming method. This Guide will walk you through step by step in setting up your Ademco system to talk to MyAmbience.

### **4100SM Installation:**

For wiring information refer to the 4100SM installation sheet provided with the module. Alternatively, you may refer to the Ademco Vista Installation and Setup Guide's 4100SM installation for home automation section.

### **Programming:**

All programming is done through the Ademco keypad. From the System Ready Screen follow these keypad presses.

4140	(default installers code)
8000	(enter programming)
*05	(System Events Notify location)
1	(enable)
*14	(Burglary or RS232 location)
1	(RS232)
*94	(goto page 2 of locations)
*70	(Event Log Types)
1	(enable alarm logging)
1	(enable Check logging)
1	(enable Bypass logging)
1	(enable Open/Close logging)
1	(enable System logging)
*99	(return to page 1 of locations)
*99	(exit programming)